

Chafer Dish Instructions



1. Place 2 cups of water in the bottom pan (the deepest pan).
2. Place food in liner (insert).
3. Keep lid on chafer in order to keep food warm.
4. **DO NOT ALLOW STERNOS TO BURN UNLESS THERE IS PLENTY OF WATER IN THE WATER PAN.** Failure to keep water in the water pan will result in burning and will ruin the chafer unit.

Chafer Hints

- Place cover back on the food when not serving this will keep it hot.
- A **sizzling** noise means the water is too low, add water immediately.
- A full size pan should cover the water pan to prevent steam from getting into the food or your food can get soggy.
- Extinguish the sterno flame by placing the cover over the sterno holder when done. Never leave the flame unattended.
- Never use the Chafer without water in the pan - your food will burn and this may cause damage
- The unit is designed for keeping food warm you must pre-cook it.

